

Enerest ToGo

Monitoring in your pocket

Our app is free to download for Apple and Android devices. You can use all the features as a provider of professional monitoring services, but you can also recommend the app to your customers.

Time-saving support for use on the construction site. The app notifies you when Solar-Log WEB Enerest™ 4 reports new alarms from your PV plants. While on the move, you decide whether these should be followed up or archived.



Own consumption at a glance

The app gives your customers an overview of all production and consumption values. This enables you to focus on monitoring and service.






Reports and alerts

Push notifications let you know immediately when alarms occur at your customers' plants. This means you are always informed and can respond quickly. Enable notifications for the entire portal or just for individual important plants

Yield and balance reports automatically provide your customers with informative summaries about their plants. You save valuable time and your customers are kept fully informed.





Added value and benefits

Real-time monitoring

Our mobile app allows you, as a professional, to monitor your customers' PV systems in real time from anywhere and receive up-to-date information on energy flows and alarms.

Service toolbox

- Create plant
- Device replacement
- Transmission test

Secure data transmission

Communication between the Solar-Log WEB Enerest™ 4 Portal and the mobile app is secured using the latest standards. Users can protect their account with two-factor authentication.

Free updates

We regularly release new features and bug fixes. We are constantly developing Enerest ToGo.

Inverter Inverter Energy flow Consumption Balance Target production Charging station Battery Simulated battery Green Energy Green Energy Self-ourficiency Self-	Enerest ToGo function overview	Installers	Plant owners
Energy flow Consumption Balance Target production Charging station Battery Simulated battery Green Energy Self-sufficiency Self-sufficiency Self-sufficiency Self-sufficiency Self-consumption REPORTS View alarms To a large through the self-sufficiency Plant status To consumption Reports View alarms An	Graphics		
Energy flow Consumption Balance Target production Charging station Battery Charging station Battery Simulated battery Green Energy Self-sufficiency Self-consumption Self-consu		•	•
Balance Target production Charging station Battery Battery Simulated battery Green Energy Self-sufficiency Self-sufficiency Self-consumption Reports View alarms Live alarm notifications Plant status Yield report Operator report Operator report Operator seport Shortication centre Operator seport Shortication centre Operator seport Op		•	•
Target production Charging station Battery Simulated battery Green Energy Self-sufficiency Self-consumption Reports View alarms Live alarm notifications Plant status Yield report Operator report Operator report Operator report Notification centre Monitoring Fleet Plant info Create plants with QR code scanner Transmission test Device replacement Service Create support tickets Tutorial Find plants and fleets (plants only) Add plant image	Consumption	•	•
Charging station Battery Simulated battery Green Energy Self-sufficiency Self-consumption Reports View alarms Live alarm notifications Plant status Operator report Notification centre Monitoring Fleet Plant info Create plants with QR code scanner Transmission test Device replacement Device replacement Service Create support tickets Tutorial Find plants and fleets Add plant image (plants only) Add plant image Service (plants only) Add plant image	Balance	•	•
Charging station Battery Battery Simulated battery Green Energy Self-sufficiency Self-sufficiency Self-consumption Reports View alarms Live alarm notifications Plant status Yield report Operator report Notification centre Monitoring Fleet Plant info Create plants with QR code scanner Transmission test Device replacement Service Create support tickets Tutorial Find plants and fleets Add plant image (plants only) Add plant image A Service (plants only) Add plant image		•	•
Simulated battery Green Energy Self-sufficiency Self-consumption Reports View alarms Live alarm notifications Plant status Self-consumption Plant status Self-consumption Self		•	•
Green Energy Self-sufficiency Self-sufficiency Self-consumption Reports View alarms Live alarm notifications Plant status Plant status Self-sufficiency Self-consumption Reports View alarms Self-sufficiency Sel	Battery	•	•
Green Energy ● Self-sufficiency ● Self-consumption ● Reports View alarms Live alarm notifications ● Plant status ● Yield report ● Operator report ● Notification centre ● Monitoring ● Fleet ● Plant info ● Create plants with QR code scanner ● Transmission test ● Device replacement ● Service Create support tickets ● Tutorial ● Find plants and fleets ● Add plant image ●		•	•
Self-consumption •	Green Energy	•	•
Reports View alarms - Live alarm notifications - Plant status - Yield report - Operator report - Notification centre - Monitoring Fleet - Plant info - Create plants with QR code scanner - Transmission test - Device replacement - Service Create support tickets - Tutorial - Find plants and fleets - Add plant image -	Self-sufficiency	•	•
View alarms - Live alarm notifications	Self-consumption	•	•
Live alarm notifications	Reports		
Plant status Yield report Operator report Notification centre Monitoring Fleet Plant info Create plants with QR code scanner Transmission test Device replacement Service Create support tickets Tutorial Find plants and fleets Add plant image - - - - - - - - - - - - -	View alarms	•	-
Yield report Operator report Notification centre Monitoring Fleet Plant info Create plants with QR code scanner Transmission test Device replacement Service Create support tickets Tutorial Find plants and fleets Add plant image	Live alarm notifications	•	-
Operator report Notification centre Monitoring Fleet - Plant info Create plants with QR code scanner Transmission test Device replacement Service Create support tickets Tutorial Find plants and fleets (plants only) Add plant image		•	-
Notification centre Monitoring Fleet - Plant info Create plants with QR code scanner Transmission test - Device replacement Service Create support tickets Tutorial Find plants and fleets - (plants only) Add plant image		•	•
Monitoring Fleet	Operator report	•	-
Fleet	Notification centre	•	•
Plant info Create plants with QR code scanner Transmission test Device replacement Service Create support tickets Tutorial Find plants and fleets Add plant image Oreate support (plants only)	Monitoring		
Create plants with QR code scanner - Transmission test - Device replacement - Service Create support tickets - Tutorial - Find plants and fleets - Add plant image - (plants only)	Fleet	•	-
Transmission test - Device replacement - Service Create support tickets - Tutorial - Find plants and fleets - Add plant image - (plants only)	Plant info	•	•
Device replacement - Service Create support tickets - Tutorial - Find plants and fleets - Add plant image - (plants only)	Create plants with QR code scanner	•	-
Service Create support tickets Tutorial Find plants and fleets Add plant image (plants only)	Transmission test	•	-
Create support tickets Tutorial Find plants and fleets (plants only) Add plant image	Device replacement	•	-
Tutorial • • (plants only) Add plant image • • • • • • • • • • • • • • • • • • •	Service		
Find plants and fleets • (plants only) Add plant image • •	Create support tickets	•	•
Add plant image	Tutorial	•	•
	Find plants and fleets	•	(plants only)
User settings • •	Add plant image	•	•
	User settings	•	•



